

Operation manual

Pen type visual fault detector



1. Please place batteries in accordance with the photo instruction to avoid improper work or damage to the equipment.
2. Switch upwards to turn the lights on, downwards to twinkle and middle to shut down.

Technical parameter

Model Number Suffix	1	10	15	20	30	50	60	80	100
Output optical power	>1mW	>10mW	>15mW	>20mW	>30mW	>50mW	>60mW	>80mW	>100mW
Output wavelength	650nm ± 10nm								
Fiber optic adapter	Universal connector								
Use temperature	0~+60Centigrade								
Storage temperature	-20~+70Centigrade								
Battery type	5 alkaline battery 2								
Battery life	> 40h	> 12h	> 10h						
Appearance	175mm*26mm*26mm								
Weight	160g								

Product quality assurance card

Product name:pen type visual fault locator

Warranty coverage:

A. The product with any hardware or software fault caused by product quality period to be returned manufacturer or authorized customer service center for repair free of charge.

B. Under any of these situation, the product not to be repaired free of charge:

1.defect liability period expired 2.product to be used,maintained or kept uninaccordance with the instruction.

3.disposable battery box is consumable material. 4.not repairable damage caused by transpotation. 5.accident or force majeure.