

# TUYA Fingerprint Lock V2.1

## 1.Specifications:

### 1.1 Technical parameters:

| Item                         | Value              | Item             | Value                           |
|------------------------------|--------------------|------------------|---------------------------------|
| <b>Operating power</b>       | 4pcs dry batteries | <b>Capacity</b>  | Finger 50, Card or Passcode 249 |
| <b>Operating current</b>     | < 135mA            | <b>Emergency</b> | Usb 5v                          |
| <b>Operating temperature</b> | -10℃—60℃           | <b>Card type</b> | Mifare                          |

### 1.2 Factory Default:

| Item                                                                                                                            | Value                                                                    |
|---------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| <b>Default Menu</b>                                                                                                             | Press "0 #" to enter Menu, Enter default admin passcode "123456" and "#" |
| Press button on the back 5 Seconds, hear "du du du", then stop pressing, it can exchange mode "Normal Open" and "Auto Lock"     |                                                                          |
| Press button on the back 15 Seconds, hear "du", then stop pressing, wait about 10 Seconds, hear "Factory restoration succeeded" |                                                                          |

### 1.3 Tuya app steps


1. Download and install TUYA app from the app store
2. Follow the prompts to register or log in:
3. Add device:

After logging in, click the [Add device] button, or click the plus sign in the upper right corner to add;

On the Add Device page, select Add Device (you need to allow location permission and Bluetooth);

And broadcast "Please pair administrator", input the fingerprint or password of the administrator (the initial unregistered password is "123456 #") to pair;

After successful pairing, perform APP operation as required;



### Installation Video :

<https://m.v.qq.com/z/msite/play-short/index.html?vid=b335981ahi9>



## 2. Programming Guide

Press "0" "#" to enter the menu, Enter Administrator Authentication, default admin passcode "123456" and "#", then as follow :

Remark: "\*" to return, "#" to confirm.

Remark: All password can be 6~10digits.

|                                 |                                          |                                                   |
|---------------------------------|------------------------------------------|---------------------------------------------------|
| Press "1" Administrator Setting | Press "1" Add Administrator              |                                                   |
|                                 | Press "2" Delete Administrator           |                                                   |
| Press "2" Common Users Setting  | Press "1" Add Common Users               |                                                   |
|                                 | Press "2" Delete Common Users            |                                                   |
|                                 | Press "3" Add Remote Control             |                                                   |
|                                 | Press "4" Delete Remote Control          |                                                   |
| Press "3" SystemSetting         | Press "1" Time Setting                   |                                                   |
|                                 | Press "2"Function Setting                | Press "1" Language Setting (1 Chinese; 2 English) |
|                                 |                                          | Press "2" Anti demolition setting (Open or Close) |
|                                 |                                          | Press "3" Normally open mode (Open or Close)      |
|                                 |                                          | Press "4" Return to factory (# to confirm)        |
|                                 | Press "3" Volume Adjustment              | Press "1" increase Volume                         |
|                                 |                                          | Press "2" decrease Volume                         |
|                                 |                                          | Press "3" Enable Mute Mode                        |
|                                 | Press "4" One Key Unlock (Open or Close) |                                                   |
| Press "4" Others Setting        | Press "1" Event record                   |                                                   |
|                                 | Press "2" Administrator statistics       |                                                   |
|                                 | Press "3" General user statistics        |                                                   |
|                                 | Press "4" Version information            |                                                   |